

KURYAKYN

METRIC (BMW, Ducati, Triumph, Can-Am) - FOOTPEG AND FLOORBOARD ADAPTERS

FOR TRIUMPH®									
		CHROME (TAPERED)		CHROME (SPLINED)		GLOSS BLACK (T)		GLOSS BLACK (S)	
FITMENT	YEAR	FRONT	REAR	FRONT	REAR	FRONT	REAR	FRONT	REAR
Rocket III	All	8840	7939	8813	8808	N/A	8868	N/A	8889
Thunderbird	95-'03	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
Thunderbird Sport	98-'00, '03	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
Thunderbird/Storm	10-'18	8840	8802	8841*	8841*	N/A	8866	N/A	8862
Adventurer	96-'01	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
Legend	99-'01	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
Bonneville T100	01-'18	N/A	8840	N/A	8841*	N/A	N/A	N/A	N/A
Bonneville SE	96-'01	N/A	8840	N/A	8841*	N/A	N/A	N/A	N/A
Bonneville America	02-'10	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
Speedmaster	03-'19	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
America	10-'17	8840	8840	8841*	8841*	N/A	N/A	N/A	N/A
		SATIN BLACK (T)		SATIN BLACK (S)		SILVER (T)		SILVER (S)	
	YEAR	FRONT	REAR	FRONT	REAR	FRONT	REAR	FRONT	REAR
Rocket III	All	N/A	N/A	8905*	N/A	N/A	N/A	8906*	N/A
Thunderbird	95-'03	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*
Thunderbird Sport	98-'00, '03	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*
Thunderbird/Storm	10-'18	N/A	N/A	8905*	N/A	N/A	N/A	8906*	N/A
Adventurer	96-'01	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*
Legend	99-'01	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*
Bonneville T100	01-'19	8875	N/A	8874	8905*	N/A	N/A	8904	8906*
Bonneville SE	96-'01	8875	N/A	8874	8905*	N/A	N/A	8904	8906*
Bonneville America	02-'10	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*
Speedmaster	03-'19	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*
America	10-'17	N/A	N/A	8905*	8905*	N/A	N/A	8906*	8906*

*Will not work with Swept Wing Pegs P/N 4466 & 4467

FOR CAN-AM®									
		CHROME (TAPERED)		CHROME (SPLINED)		GLOSS BLACK (T)		GLOSS BLACK (S)	
FITMENT	YEAR	FRONT	REAR	FRONT	REAR	FRONT	REAR	FRONT	REAR
Spyder RS	'08-'16	7939	8848	8808	N/A	8868	N/A	8889	N/A

KURYAKYN

METRIC (BMW, Ducati, Triumph, Can-Am) - FOOTPEG AND FLOORBOARD ADAPTERS

FOR BMW®							
		SATIN BLACK (T)		SATIN BLACK (S)		SILVER (S)	
FITMENT	YEAR	FRONT	REAR	FRONT	FRONT	FRONT	FRONT
BMW R NineT (except Scrambler, Pure Racer, and Urban)	'14-'20	8873	N/A	8872	N/A	8902	N/A

FOOTPEG ADAPTERS

Kuryakyn floorboards and footpegs feature a two-part mounting system. Depending on the style you choose, each floorboard or footpeg will require either a SPLINED or TAPERED adapter (sold in pairs). Use the chart below to determine the right adapter.



FOR DUCATI®							
		SATIN BLACK (T)		SATIN BLACK (S)		SILVER (S)	
FITMENT	YEAR	FRONT	REAR	FRONT	REAR	FRONT	REAR
Ducati Scrambler Models Icon, Urban Enduro, Full Throttle, Classic, Sixty2, Desert Sled and Café Racer	'15-'18	8871	8871	8870	8870	8903	8903