



FORK SKINS

8625

FITS H-D MODELS: SINGLE DISC 39MM FRONT ENDS, '88-'89 XL. FXD (EX. FXDX, FXDC, FXDWG) '87-'94 FXRS, FXR, FXLR

PART#	INCLUDED
908628	1 Narrow Fork Brace – Chrome
	2 Fork Brace Inner Clamp Half – Chrome
	1 Left Fork Skin – Chrome (Caliper Cutout)
	1 Right Fork Skin – (No Cutout)
	1 Right Axle Cap – W/O Threads
	1 Left Axle Cap – Threaded
	2 Axle Cap Carriers
	1 Hardware Kit, Including:
	4 1/4"–20 x 1" B.S.C.S. – Chrome
	2 8–32 x 1/4" Setscrews–Stainless Steel
	2 1/4"–20 x 5/8" Setscrews – Stainless Steel
	4 1/4"–20 x 1" S.H.C.S. – Chrome
	1 1/2"–20 Flanged Prevailing Torque Nut
	1 Fork bottom centering bracket-not used
	2 1/8" x 3/8" O-Ring
2 Fork Bottom Centering Inserts – Chrome	
1 Installation Instructions	

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.


TOOLS SUGGESTED

Set of hex wrenches, set of combination wrenches, Clean rag, Foot-Pound torque wrench

PROCEDURE

STEP 1 Prep the fork sliders. See PIC.1. Place the O-ring in the groove on the chrome centering inserts as shown. Slide the inserts into the holes in the bottom of the fork sliders. See PIC.2. The O-ring serves only to keep the insert in place during installation.

-cont.-



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



STEP 2 Remove the front axle nut, split lock washer, and flat washer from the front axle. Replace these three components with the flanged, prevailing torque lock nut included in the kit. This nut provides all of the functions of the three OEM components, but allows more thread to protrude through the nut. Torque the new axle nut to 50 foot-pounds. See [PIC.3](#). Install the chrome axle caps with the plastic carriers in place. The right side simply slides on, and the left side screws on. Both are held in place with the 8-32 setscrew.

STEP 3 Place a clean rag on top of the front fender between the fork tubes to guard against scratching. Slightly loosen the four button head cap screws securing the inner clamp halves to the fork brace. Carefully insert this fork brace assembly between the fork sliders and hold it in place.

STEP 4 See [PIC.4](#). Set one of the fork covers into position on the slider. The axle cap should protrude through the Fork Skin on the bottom. Secure the fork brace to the top of the Fork Skin with two 1/4"-20 x 1" socket head cap screws, loosely for now. Repeat this procedure in the remaining side of the front end.

STEP 5 At the very bottom of each Fork Skin, insert one of the 1/4"-20 x 5/8" setscrews, but do not tighten yet.

STEP 6 Adjust the height of the fork brace on each side. The fork brace should clamp on to the fork slider in the same position on each side. The hole at the bottom of the Fork Skin should be centered as closely as possible around the axle caps. Tighten the clamps on to the sliders on each side, snug only for now.

STEP 7 Tighten the Button Socket Cap Screws securing the fork brace to the inner clamp halves to 7-8 foot-pounds. Be sure the Fork Skin clamps are in line with the fork brace.


STEP 8 Tighten the socket head cap screws securing the Fork Skins to the inner clamp halves to 7-8 foot-pounds. Make sure the gaps in the front and rear of the clamp are equal.

STEP 9 Tighten the set screws in the bottom of the fork skins so they index into the centering devices on the bottom of each fork slider.

WARNING! DO NOT OVER TIGHTEN THESE SETSCREWS – TIGHTEN TO SNUG ONLY!

Ride On!

PIC.3



PIC.4

